



STEP ① - Cut out the Clip-Lock on the panel in the area as shown.

STEP ② - Cut out the required vent hole into the Shingle XD panel and roof deck

STEP ③ - Place under pan (if required) onto roof deck. Lock the front portion of the underpan onto remaining Clip-Lock as shown.

STEP ④ - Place Box vent over DECRA Shingle XD and Underpan and fasten to deck. Caulk as required.

STEP ⑤ - Cut in the next course DECRA Shingle XD around box vent and fasten to deck.

TITLE

**Box Vent Detail – Shingle XD**

DRAWING No.

**Shingle XD Box Vent Detail**

**DECRA ROOFING SYSTEMS, INC.**

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF DECRA ROOFING SYSTEMS, INC. ANY REPRODUCTION IN PART OR IN WHOLE WITHOUT PRIOR APPROVAL AND WRITTEN PERMISSION IS PROHIBITED.

1230 RAILROAD ST. CORONA, CA 92882 PH (951)272-8180 Fax (951)272-4476

DATE: **22-04-06**

SCALE: **None**