




DECRA Ridge Vent



Flat Sheet



Corrosion-resistant Screws

DECRA panel vents should be installed on the last full course below the ridge, and no more than 4 feet down from the peak of the roof facet. Panel vents should NOT be used for air intake.