


Install Shingle XD<sup>®</sup> on standard roof slopes of 4:12 and greater.



DECRA panel vents should be installed on the last full course below the ridge, and no more than 4 feet down from the peak of the roof facet. Panel vents should NOT be used for air intake.

Use 2 x 2s and / or 1 x 2s at hips and ridges. Additional build up may be required depending on roof slope.